

## 650 Membrane Cold Weather Application Suggestions

The procedure for applying 650 Membrane in low temperatures will be the same as listed on our 650 Data sheet with the exception of:

- All material must be kept in room condition areas and not out on the jobsite.
- Substrate to receive membrane must be dry and frost free.
- Recommended application temperature are between 25° F (4° C) and 60° F (16° C).
- The 650 LT Liquid Adhesive and California Sealant dry times will be longer due to ambient and substrate temperatures, humidity and thickness applied. Prior to membrane application adhesive or Sealant as in any condition, will be tacky to touch but not wet. This process could take minutes to hours depending on weather and/or substrate conditions.
- 650 WB Liquid Adhesive is a water based adhesive and cannot be applied in temperatures below freezing. Cold temperature applications will take many hours for the evaporation process to create the tack needed for installation of the membrane.
- Membrane must be rolled with a laminate roller for added adhesion.
- Backfill should be done immediately to enhance adhesion of membrane to substrate.

**DISCLAIMER:** The information contained in this document is based on data and knowledge considered to be true and accurate at time of printing and is offered for the users' consideration, investigation and verification. Polyguard Products, Inc. cannot be held liable for errors made as a result of information herein. Changes and modifications can be made to this document without prior notice. No statement, recommendation or suggestion is intended for use which would infringe on patents or copyrights held by Polyguard Products, Inc.